

Fuel Shut off Tap



Installation Instructions

The fuel taps come with fittings that screw into the body of the valve. As these threads are an 'NPT' (*National Pipe Taper*) thread, the more the fittings are screwed into the body, the more the threads seal. Before screwing the fittings into the body, you **MUST** install PTFE tape to threads. To install the PTFE tape:

1. Looking at the base of the thread, you should apply the tape on in a clockwise motion
2. All threads should receive 3 wraps of PTFE tape to get required seal
3. Screw fittings into the body of the valve with a spanner until they are tight.

Technical Support

Should you experience any problems or difficulties when using this product, please contact the following service centre for further assistance:



McGill Motorsport Ltd, Unit 1, Block 9, Muirhead, Mitchelston Ind Est, Kirkcaldy, Fife, KY1 3PE, UK

+44 (0)1592 654136 | contact@mcgillmotorsport.com | www.mcgillmotorsport.com